USER'S GUIDE FOR BATH THERMOMETER

(WT-28,WT-29, WT-30)

Please read the instructions carefully to ensure accurate temperatures and safe operation.

IMPORTANT SAFETY INFORMATION:

- Do not allow children to take bath temperature unattended.
- Never leave children alone and unsupervised in the bath.
- The bath thermometer is only a simple water temperature indicator. Always check the temperature of the bath water with the back of your hand before putting child into bath.
- Do not use thermometer if broken or damaged.
- Do not place it into water beyond 70° C.
- Do not recharge battery. Properly dispose of the battery, keeping it from small children and heat.
- Always replace with new battery.

FEATURES:

- Measurement range: 0° C to 70° C
- When LCD flashes, the cell batteries are exhausted.
- When water temperature is higher than 70° C, the LCD displays "Hi" and it displays "Lo" when water temperature is lower than 0° C.

OPERATION:

- Press the On/Off button; the LCD displays the room temperature.
- When water temperature ranges from 38° C to 42° C, LED lights persistently, which means the temperature is suitable for bath.
- Press and hold the On/Off button for two seconds to enter turnoff status.
- Put the Bath Thermometer on the water, LCD displays the accurate water temperature within 90 seconds.

HOW TO CARE FOR THIS PRODUCT:

- Clean the thermometer by using isopropyl alcohol or soap and water before and after use.
- Store Bath Thermometer in a cool, dry place and away from direct sunlight while not in use.
- Do not open the bath thermometer except to replace the battery.
- Do not drop the thermometer, as this may ruin the unit.
- Turn off the bath thermometer soon after use to save battery and prolong the battery life.

CHANGING THE BATTERY:

- Make sure a battery of the same type is on hand.
- Remove battery compartment lid with screwdriver.
- Replace the batteries.
- Properly dispose of the old batteries.